




















PERSVOETEN - PIEDS PRESSEUR - PRESSER FEET FOR KENMORE

 <p>Ref : 213503015 Foot buttonhole low Kenmore 158</p> <p>077.213.503</p>	 <p>Ref : 35231 Foot ZZ front loading Kenmore 385</p> <p>077.035.231</p>	 <p>Ref : 55551 Foot ZZ super high Kenmore 158</p> <p>077.055.551</p>
 <p>Ref : 55571 Foot straight stitch Kenmore</p> <p>077.055.571</p>	 <p>Ref : 556231 Foot satin st. super Kenmore 158</p> <p>077.556.231</p>	 <p>Ref : 56451 Foot buttonhole Kenmore super high</p> <p>077.056.451</p>
 <p>Ref : 60161 Foot button sew-on Kenmore 158 super high</p> <p>077.060.161</p>	 <p>Ref : 60221 Foot braiding Kenmore 158 super high</p> <p>077.060.221</p>	 <p>Ref : 650504002 Foot ZZ Kenmore 385 series</p> <p>077.650.504</p>
 <p>Ref : 650802014 Foot straight stitch Kenmore 385 low front</p> <p>077.650.802</p>	 <p>Ref : 652507012 Foot complete Kenmore 385 top load</p> <p>077.652.507</p>	 <p>Ref : 652806025 Foot straight stitch Kenmore 385 front loading</p> <p>077.652.806</p>
 <p>Ref : KM34478 Foot satin stitch Kenmore plastic super high</p> <p>077.034.478</p>	 <p>Ref : KM39196 Foot overcast Kenmore</p> <p>077.039.196</p>	 <p>Ref : KM43852 Foot buttonhole Kenmore super high</p> <p>077.043.852</p>
 <p>Ref : KM45696 Foot straight stitch Kenmore super high center</p> <p>077.045.696</p>	 <p>Ref : KM56481 Foot shank Kenmore super high</p> <p>077.056.481</p>	 <p>Ref : KM6759 Foot invisible zipper Kenmore 158 super high</p> <p>077.006.759</p>
 <p>Ref : KM6784 Foot knitting Kenmore super high</p> <p>077.006.784</p>	 <p>Ref : KM6794 Foot zipper Kenmore 158 super high</p> <p>077.006.794</p>	 <p>Ref : RWA7 Foot walking Kenmore low</p> <p>077.010.006</p>
 <p>Ref : RWA8 Foot walking Kenmore super high including SKL screw</p> <p>077.010.050</p>	 <p>Ref : P60666 Adaptor foot Kenmore super high/low. Adaptor to allow use of low shank feet on Kenmore Super high. Inl. thumb screw.</p> <p>077.060.666</p>	<p>Ref : 55824 B Guide buttonhole Kenmore 158.13580</p> <p>077.055.824</p>
 <p>Ref : P17310 Quilting foot Kenmore low</p> <p>077.017.310</p>	 <p>Ref : P29303 Hemmer foot Snap-on 3/8"</p> <p>077.029.303</p>	<p>Ref : KM6765 Roller foot Kenmore</p> <p>077.006.765</p>
 <p>Ref : P29315 Hemmer foot bracket Kenmore high</p> <p>077.029.315</p>	<p>Ref : 823504015 Shank Kenmore 385 top load</p> <p>077.823.504</p>	 <p>Ref : 611520003 Presser foot Kenmore</p> <p>077.611.520</p>

