

NAALDSTANGKRUKJES - BIELLE BAR AIGUILLE - CRANK SLIDES



Ref : 137528-901
 Crank slide
 Singer 6408-6423

077.137.528



Ref : 137720051
 Crank side
 Brother 845
 Babylock BL700

077.137.720



Ref : 313533
 Crank slide
 Singer 4613/7/23, 623

077.313.533



Ref : 352753
 Crank slide
 Singer 4522, 4528, 4530

077.352.753



Ref : 382776
 Crank slide
 Singer 2000, 2005

077.382.776



Ref : 383267
 Crank slide
 Singer 2001, 2010

077.383.267



Ref : 383286
 Crank slide
 Singer 900, 920, 925

077.383.286



Ref : 4114948-01
 Crank slide
 Viking 2000

077.411.494



Ref : 445224
 Crank slide
 Needle bar connecting link
 Singer 240, 250 series

077.445.224



Ref : 446357
 Crank slide
 Needle bar connecting link
 Singer 1812, 6200

077.446.357



Ref : 5611
 Rod needle bar crank
 White

077.005.611



Ref : 75060
 Crank
 Singer 2638, 132, 1500

078.075.060



Ref : HA-1-20
 Crank slide
 Alphasew HA-1

077.000.120



Ref : X52751050
 Crank slide
 Brother XL2010, 2015,
 2021, 2022, 2025, 2030,
 XR29/23

077.527.510



Ref : X55944051
 Crank needle bar
 Brother PC7000, PC7500,
 PC8000, PC8895
 Babylock ESI, ESI2

077.559.440



Ref : X55991051
 Crank slide
 Brother PC7000, PC7500,
 PC8000, PC8895
 Babylock ESI, ESI2

077.559.910



Ref : X56822051
 Crank slide
 Brother PS1900, 1950,
 2100
 Babylock BL6700

077.568.220



Ref : X57745051
 Crank slide
 Brother PC5000, 6500
 Babylock BL9500

077.577.450



Ref : 6956
 Crank slide
 White 1505, 1510

077.006.956