










BLINDE RITSVOETEN - PIEDS TIRETTE INVISIBLE - CONCEALED ZIPPER FEET

 <p>Ref : 941800000 Zipper foot Concealed low/laag/bas</p> <p>077.941.800</p>	 <p>Ref : 942800000 Zipper foot High concealed/hoog/haut</p> <p>077.942.800</p>	 <p>Ref : 943800000 Zipper foot Slant concealed/schuin/oblique</p> <p>077.943.800</p>
 <p>Ref : 941100000 Concealed zipper foot Low adjustable/laag/bas</p> <p>077.941.100</p>	 <p>Ref : 941100002 Zipper foot Hoog/haut/high concealed adjustable</p> <p>077.941.102</p>	 <p>Ref : 941100003 Concealed zipper foot Schuin/oblique/slant adjustable</p> <p>077.941.103</p>
 <p>Ref : NP63P = 148475001 Invisible foot Brother PQ1300-PQ1500 Hoog/haut/high</p> <p>071.321.868</p>	 <p>Ref : 217-75015 Conceal fastener foot Laag/bas/low shank, M position, transparent</p> <p>077.217.750</p>	 <p>Ref : 107-75015 Conceal fastener foot Hoog/haut/high shank, M position, transparent</p> <p>077.107.750</p>
 <p>Ref : 217-72009 Conceal fastener foot Laag/bas/low shank, M position</p> <p>077.217.720</p>	 <p>Ref : 107-72009 Conceal fastener foot Hoog/haut/high shank, M position</p> <p>077.107.720</p>	 <p>Ref : NP63PL low plastic laag wit / voor huishoudmachine ILK-2CKJ <i>bas plastique blanc / pour machine ménage ILK-2CKJ</i></p> <p>071.321.866</p>
 <p>Ref : NP63P high wit plastic ILK-2CJ1 <i>plastique blanc ILK-2CJ1</i> Hoog/haut/high</p> <p>071.321.865</p>	 <p>Ref : NP163G Nippo Hoog/haut/high</p> <p>071.321.863</p>	 <p>Ref : NP163GT Teflon Hoog/haut/high</p> <p>071.321.867</p>
 <p>Ref : 283400 Zipper foot concealed Singer Quantum CXL-LE-XL1</p> <p>077.283.400</p>	 <p>Ref : PD5011-21 Zipper foot concealed Babylock ESE-ESE2 Brother PE8200-PE8500</p> <p>077.501.127</p>	 <p>Ref : XC1947002 Zipper foot concealed Brother</p> <p>077.194.702</p>