

KNOOPSGATEN APPARATEN + ZIG ZAG
APPAREILS BOUTONNIERE + ZIG ZAG
BUTTON HOLDER ATTACHMENTS + CUTTER SIDE + ZIG ZAG



Ref : 3700L
 Ringer fancy low shank.
 Makes a variety of circular flower like patterns by adjusting, machine, and by using different colored thread.
077.003.700



Ref : 3
 Buttonholder Janome free rotary
077.300.000



Borduurset
 Set à broder



Ref : R-CT8=R-CT1
 Attach cut & sew
 Deluxe low shank+slant shank
 Cuts the fabric on the right hand side of the zigzag stitch as the material is seen.
075.000.009



Ref : J6140
 Buttonholder maker for 305
077.006.140



Ref : R-CT10-L
 Attach trimming & hemming
 Low center/laag/bas
 This attachment does trimming and overcasting on zigzag machines, just like a mini-serger.
077.000.019



Ref : R-CT10-S
 Attach trimming & hemming
 Slant/schuin/oblique
 This attachment does trimming and overcasting on zigzag machines, just like a mini-serger.
077.000.020



Ref : RB-LC
 Buttonholder low shank
 Laag / bas
077.010.008



Ref : RB-S
 Buttonholder Ruby slant
 Schuin / oblique
077.010.009



Ref : X80943001 **077.809.430**
 Cutter side
 Brother ULT2001/2002,
 PE8500
 Babylock ESG Ellageo
Ref : X81028001 **077.810.280**
 Brother PE8200
 Babylock ESE



Ref : R-CX20
 Snap-on side cutter 6mm.
 Singer
 Brother
 Babylock
077.000.021



Ref : YS-4454
 Buttonholder heavy duty
 Low shank / laag / bas
077.004.454



Ref : YS-7
 Zigzagger low shank/laag/bas
 With 4 templates
077.700.000



Ref : Z6000
 Zigzag attachment
077.600.000