

NAALDSTANGKRUJKES - BIELLE BAR AIGUILLE - CRANK SLIDES

 <p>Ref : 137528-901 Crank slide Singer 6408-6423</p> <p>077.137.528</p>	 <p>Ref : 137720051 Crank side Brother 845 Babylock BL700</p> <p>077.137.720</p>	 <p>Ref : 313533 Crank slide Singer 4613/7/23, 623</p> <p>077.313.533</p>
 <p>Ref : 352753 Crank slide Singer 4522, 4528, 4530</p> <p>077.352.753</p>	 <p>Ref : 382776 Crank slide Singer 2000, 2005</p> <p>077.382.776</p>	 <p>Ref : 383267 Crank slide Singer 2001, 2010</p> <p>077.383.267</p>
 <p>Ref : 383286 Crank slide Singer 900, 920, 925</p> <p>077.383.286</p>	 <p>Ref : 4114948-01 Crank slide Viking 2000</p> <p>077.411.494</p>	 <p>Ref : 445224 Crank slide Needle bar connecting link Singer 240, 250 series</p> <p>077.445.224</p>
<p>Ref : 446357 Crank slide Needle bar connecting link Singer 1812, 6200</p> <p>077.446.357</p>	 <p>Ref : 5611 Rod needle bar crank White</p> <p>077.005.611</p>	 <p>Ref : 75060 Crank Singer 2638, 132, 1500</p> <p>078.075.060</p>
 <p>Ref : HA-1-20 Crank slide Alphasew HA-1</p> <p>077.000.120</p>	 <p>Ref : X52751050 Crank slide Brother XL2010, 2015, 2021, 2022, 2025, 2030, XR29/23</p> <p>077.527.510</p>	 <p>Ref : X55944051 Crank needle bar Brother PC7000, PC7500, PC8000, PC8895 Babylock ESI, ESI2</p> <p>077.559.440</p>
 <p>Ref : X55991051 Crank slide Brother PC7000, PC7500, PC8000, PC8895 Babylock ESI, ESI2</p> <p>077.559.910</p>	 <p>Ref : X56822051 Crank slide Brother PS1900, 1950, 2100 Babylock BL6700</p> <p>077.568.220</p>	 <p>Ref : X57745051 Crank slide Brother PC5000, 6500 Babylock BL9500</p> <p>077.577.450</p>
 <p>Ref : 6956 Crank slide White 1505, 1510</p> <p>077.006.956</p>		