






**KLIKVOETEN - PIEDS CLIC-CLAC - FEET SNAP-ON
 SINGER LAAG/BAS/LOW**

 <p>Ref : 446014 Includes 446014-1, 446014-2 and 446014-3 (3pc. kit)</p> <p>077.446.014</p>	 <p>Ref : 446014-1 = 155964 Presser bar shank low</p> <p>077.446.015</p>	 <p>Ref : 446014-2 = 155962 Zigzag foot low</p> <p>077.446.016</p>
 <p>Ref : 446014-3 = 153267 = 541507 Straight stitch foot low</p> <p>077.446.017</p>	 <p>Ref : 10400 L Blindhem foot Singer low</p> <p>077.010.400</p>	 <p>Ref : 161927 Foot buttonhole plastic Singer low</p> <p>077.161.927</p>
 <p>Ref : 161956 Foot overcast Singer low snap-on</p> <p>077.161.956</p>	 <p>Ref : 171498 Foot all purpose plastic Singer low</p> <p>077.171.498</p>	 <p>Ref : 313992-451 = 313999-451 Buttonhole foot low with sliding Singer</p> <p>077.313.992</p>
 <p>Ref : 446371 Zigzag foot, snap-on, low, wide Singer</p> <p>077.446.371</p>	 <p>Ref : 423200-451 Buttonhole foot Singer 2210</p> <p>077.423.200</p>	 <p>Ref : 507836 Zipper foot snap-on Singer low</p> <p>077.507.836</p>
 <p>Ref : BFL = P60835 Cording foot low 3/16"</p> <p>077.010.001</p>	 <p>Ref : P55607 Hemmer foot Singer low snap-on 1/8"</p> <p>077.055.607</p>	 <p>Ref : P64020 Cording foot Singer low</p> <p>077.064.020</p>
 <p>Ref : P60777 Open toe embroidery foot, plastic, snap-on Singer low</p> <p>077.060.777</p>	 <p>Ref : S701L Pintuck foot, 7 grooves Singer low</p> <p>077.000.701</p>	