

















RECHTSTEEKVOETEN - PIEDS POINT DROIT - FEET STRAIGHT STITCH

 <p>Ref : 170071 Straight stitch foot Singer 301-626E1-626E6-626E7-631 077.270.071</p>	 <p>Ref : 45321 Straight stitch foot Low center narrow 077.145.321</p>	 <p>Ref : 45321 W Straight stitch foot Low center wide 077.145.322</p>
 <p>Ref : 55609 Straight stitch foot Low left narrow 077.155.609</p>	 <p>Ref : 5557 Straight stitch foot High left narrow 077.105.557</p>	 <p>Ref : 55605 Straight stitch foot Low left wide 077.155.605</p>
 <p>Ref : 55621 Straight stitch foot High left 077.155.621</p>	 <p>Ref : 55688 L Straight stitch foot Low center wide 077.055.689</p>	 <p>Ref : 55688 H Straight stitch foot High center wide 077.055.688</p>

TEFLONVOETEN - PIEDS TEFLON - FEET TEFLON

 <p>Ref : 941270000 = 1195A Zigzag foot Low teflon Laag/bas 077.941.270</p>	 <p>Ref : 941280000 Zigzag foot High teflon Hoog/haut 077.941.280</p>	 <p>Ref : 941290000 Zigzag foot Slant teflon Schuin/oblique 077.941.290</p>
 <p>Ref : 941310000 = 1189A Straight stitch foot Teflon low Laag/bas 077.941.310</p>	 <p>Ref : 941320000 Straight stitch foot Teflon high Hoog/haut 077.941.320</p>	 <p>Ref : 941330000 Straight stitch foot Teflon slant Schuin/oblique 077.941.330</p>
 <p>Ref : TN 50 = P60516 Roller foot high With slide ring Hoog/haut 071.310.710</p>	 <p>Ref : P60517 Roller foot slant With slide ring Schuin/oblique 077.060.517</p>	