

**DIVERSE HUISHOUD - DIVERS FAMILIALE**



**Ref : 70-112000-02**  
 Light switch  
 Pfaff 1221/2 electr.  
**077.112.000**




**Ref : 4114948-01**  
 Crank Slide  
 Viking 2000  
**077.411.494**



**Ref : 4117050-01**  
 Handwheel black  
 Viking S100-S110-S120-S140-  
 S150-S160-S185-S190  
**077.411.050**




**Ref : 988549-003**  
 Air transducer  
 Singer most models  
**077.988.549**



**Ref : 329.160.03=031**  
 Cord 220V (2 pole)  
 Bernina 830-740-741-742-744-750-  
 730-540-640-707-708-709-717 à 729-  
 801-804-807-808-809-830-811 à 819-  
 840 à 850  
 Non electric  
**077.329.160**



**Ref : 329.213.03**  
 Cord 220V (3 pole)  
 Bernina 830 elec.  
**077.329.213**



**Pedaal YDK zonder kabel**  
**Pédale YDK sans cordon**  
**072.110.040**



**Ref : 317.008.245 = 772814**  
**= 0040767000 = 344040.4.00**  
 Hook  
 Bernina 317, 540, 640, 740, 741, 742,  
 744, 750, 840, 841, 842, 850, 940,  
 950, 217  
 Necchi 539  
**077.317.008**



**Ref : 4111596-01**  
 Cam stack gear  
 Viking 6000  
 Imitation—Coppypart  
**077.411.596**



**Ref : 93-040708-91**  
 Gear cam stack  
 Pfaff 1222  
**077.040.708**



**Ref : 93-035314-91**  
 Position bracket  
 Pfaff 875, 905-955, 1006-1071,  
 1151/71, 1371, 1469, 1471/2/3/5  
**077.035.314**



**Ref : 93-040314-91**  
 Position bracket  
 Pfaff 1197, 1211/2/3/4, 1216/7,  
 1222, 1229  
**077.040.314**




Spoelhoudering  
 Anneau pour canettes  
**070.800.003**  
 blauw / bleu  
**070.800.002**  
 rood / rouge



**Motor Ocel/Moretti 70/18**  
 220V - 250W  
 1/6-1/3PK (HP)  
 3500/600 RPM/Tm  
**072.110.500**



**Ref : R12373210 small**  
 Spool seat small  
 Singer 3820  
**077.123.732**



Luxe vademer 3414 - 6cm.  
 Enfileur luxe 3414 - 6cm.  
**075.401.015**



**Ref : 0049307001**  
**= 0049287000**  
 Foot control with cord  
 Bernina 830, 290 type  
 met kabel / avec cable  
**077.493.070**



**Ref : 310.007.03**  
 Gear cam  
 Bernina 730/1/2, 830/1/2  
**077.310.007**