

VOETEN ZIGZAG - PIEDS ZIGZAG - FEET ZIGZAG



Ref : 5613=5613 KL
 Zigzag foot, no cut out
 Laag/bas/low shank
077.105.614
 &
077.105.613



Ref : 55622
 Zigzag foot satin
 Hoog/haut/high center
077.155.622



Ref : 5613KH
 Zigzag foot, no cut out
 Hoog/haut/high shank
077.005.613



Ref : 5555
 Zigzag foot
 Hoog/haut/high center
077.105.555



Ref : 55614
 Zigzag foot
 Laag/bas/low center
077.155.614



Ref : 55612
 Zigzag foot satin
 Laag/bas/low center
077.155.612



Ref : 172075
 Zigzag foot
 Schuin/oblique/slant
 Singer 626E1-626E6-
 626E7-631
077.272.075



Ref : 384129
 Zigzag foot complete
 Schuin/oblique/slant
077.384.129



Ref : 685502008
 Zigzag foot, type A
 Janome - Also called the all-
 purpose foot. Used for most
 utility sewing from straight
 stitch to zigzag stitching.
077.685.502



Ref : 832523007
 Zigzag foot
 Janome 5000-MC9000
077.832.523



Ref : 825510021
 Zigzag foot
 Janome 5001
077.825.510



Ref : 5616 (5616 KL)
 Zigzag foot plastic satin
 Laag/bas/low
077.105.616



Ref : 5554
 Zigzag foot plastic satin
 Hoog/haut/high
077.105.554



Ref : 76251
 Zigzag foot
 Singer 2638-2662-7422-
 7424-7426-7442-7444-
 7446-7462-7464-7466-
 7468
077.076.251



Ref : 313150
 = 163710 = 502280
 Zigzag foot wide
 Schuin/oblique/slant
 Singer 4552-4572-4622-7028-
 7037-9005-9008-9010-9410
077.313.150

Ref : 387506
 Zigzag foot
 Singer Quantum XL5000-
 XL6000
077.387.506



Ref : 386004
 Zigzag foot
 Singer Quantum XL100-
 XL1000-XL150-XL5000
077.386.004



Ref : 446014-2
 Zigzag foot
 Laag/bas/low
 Singer
077.446.016



Ref : 006806008
 Zigzag foot
 Singer 1105-1107-1116-
 1120-1130-1525
077.680.608



Ref : 730167
 Zigzag foot
 Singer 117
077.730.167



Ref : 79495
 Zigzag foot
 Singer 118
077.079.495



Ref : 77045
 Zigzag foot
 Singer 132Q-140Q
077.077.045



Ref : 541566
 Zigzag foot
 Singer P20U33-3
 (alphasew) - 20U -
 P20U143 - P20U33
085.541.566



Ref : 446371
 Zigzag foot, snap-on, wide
 Laag/bas/low
 Singer
077.446.371



Ref : 006918008
 Zigzag foot
 Singer 3820-6510-6550-
 7312-7322-7350-7358-
 7360
077.691.808



Ref : HP32969
 Zigzag foot
 Singer 9410-9420-9440
077.032.969



Ref : 85015
 Zigzag foot
 Singer 7462-CE100
 Quantum Futura-CE200
 Futura
077.085.015



Ref : 283104
 Zigzag foot
 Singer DSX-Quantum CXL-
 Quantum LE-Quantum XL1-
 Quantum XL50
077.283.104

























Ref : 137748101
 Zigzag foot
 Brother
077.137.748



Ref : XC3021051
 Zigzag foot
 Brother
 Babylock
077.302.105

VOETEN ZIGZAG - PIEDS ZIGZAG - FEET ZIGZAG

 <p>Ref : X51953001 Zigzag foot Brother Babylock</p> <p>077.519.530</p>	 <p>Ref : XC4901051 Zigzag foot Brother XL2600-XL2610- XL2620-XL3500-XL3510- XL3520</p> <p>077.490.105</p>	 <p>Ref : 941280000 Zigzag foot teflon Hoog/haut/high</p> <p>077.941.280</p>
 <p>Ref : R3 Zigzag foot, snap-on Riccar</p> <p>077.200.003</p>	 <p>Ref : 93-037905-91 Zigzag foot, snap-on, 9mm. Pfaff 301</p> <p>077.037.905</p>	 <p>Ref : 98-694847-00 Zigzag foot, snap-on, 7mm. Pfaff</p> <p>077.694.847</p>
 <p>Ref : 98-694828-00 Zigzag foot, snap-on, 7mm. Pfaff</p> <p>077.694.828</p>	 <p>Ref : 98-694816-00 Zigzag foot, snap-on, 6mm. Pfaff</p> <p>077.694.816</p>	 <p>Ref : 43522 A Zigzag foot Extra hoog/extra haut/ extra high guard Pfaff 138-238</p> <p>071.360.340</p>
 <p>Ref : 4120373 Zigzag foot Husqvarna S105</p> <p>077.412.037</p>	 <p>Ref : 4127640-01 Zigzag foot, 17mm. Husqvarna Designer 1-2</p> <p>077.412.640</p>	 <p>Ref : 425754 Zigzag foot Elna</p> <p>077.425.754</p>
 <p>Ref : 395710-03 Zigzag foot Babylock BL1108- BL1170 Elna 1010-2002- 2004-2006</p> <p>077.395.712</p>	 <p>Ref : T030057 Zigzag foot Elna 300-1500-1600</p> <p>077.030.057</p>	 <p>Ref : 494390 Zigzag foot, B foot, 7mm. Elna 8000-9000-Diva</p> <p>077.494.390</p>
 <p>Ref : 493871-20 Zigzag foot 7mm. Elna 8000-9000-Diva</p> <p>077.493.871</p>		
 <p>Ref : 5554 KH</p> <p>077.105.558</p>	 <p>Ref : 172075 = 409379 Singer</p> <p>077.272.075</p>	 <p>Ref : 175075 P</p> <p>077.272.076</p>
 <p>Ref : 5645</p> <p>077.105.645</p>	 <p>Ref : 55701 Low shank</p> <p>077.155.701</p>	 <p>Ref : 55649 Low shank</p> <p>077.155.649</p>