





















NAALDPLATEN - PLAQUES AIGUILLES - NEEDLE PLATES BROTHER
SCHUIFPLATEN - COUVERCLES GLISSIERES - COVERPLATES BROTHER

 <p>Ref : 127898-001 Rollhem plate with foot Brother B523/526 Viking 431, 530</p> <p>077.127.898</p>	 <p>Ref : 132833-001 Needle plate Brother 450, 625, 645, VX516, VX546, VX566, VX616</p> <p>077.132.833</p>	 <p>Ref : A1109-090-AAO Needle plate Juki LT98 Brother 1500 (thin material)</p> <p>077.109.090</p>
 <p>Ref : A1109-090-BAO Needle plate Juki LT98 Brother 1500 (thick material)</p> <p>077.109.091</p>	 <p>Ref : A1109-E98-ZOO Needle plate Juki LT98 Brother 1500 (reg. material)</p> <p>077.109.098</p>	<p>Ref : XC0614.0.21 Needle plate Brother PS2250, 2360, 2470</p> <p>077.000.614</p>
<p>Ref : XC8981.0.21 Needle plate Brother XL2600, 2610, 2620, 3500</p> <p>077.008.981</p>	<p>Ref : XC6063.0.21 Darning plate Brother XL2600, 2610, 2620</p> <p>077.006.063</p>	<p>Ref : XC8983.0.21 Cover plate Brother XL2600, 2610, 2620, 3500</p> <p>077.008.983</p>
 <p>Ref : NZ36LG = 130967-001 = 123142-001 = 139514-001 Needle plate Brother FA XL700, 1500, VX511-661-810-860-890-950-2051-2080</p> <p>077.300.663</p>	 <p>Ref : NZ36LG-01 Needle plate Brother VX straight stitch</p> <p>077.300.059</p>	 <p>Ref : NZ3LG Needle plate Brother 110, 190, 2100S, 210, 211, 230, 280, 290, 991, 1400, XL791 (with markings)</p> <p>077.300.600</p>
 <p>Ref : X53111.1.51 Needle plate Brother PS1700 BBL 2100, 6000</p> <p>077.053.111</p>	 <p>Ref : X54373.0.51 Needle plate Brother XL2022-XL2010-XL2031</p> <p>077.054.373</p>	 <p>Ref : X55858.2.51 Needle plate Brother PS1750 BBL 2150</p> <p>077.055.858</p>
 <p>Ref : X55859.1.51 Needle plate BBL 2150, 6150</p> <p>077.055.859</p>	 <p>Ref : X56828.1.51 C/plate Brother PC7000, PC8000, 895, ...</p> <p>077.568.281</p>	 <p>Ref : X57231.1.51 Needle plate Brother PS1900</p> <p>077.057.231</p>
 <p>Ref : X57654.0.51 Needle plate Brother PC6000, B825</p> <p>077.057.654</p>	 <p>Ref : X57753.0.01 = X57785-001 = X57784-001 Needle plate Brother PC5000 BBL 9500</p> <p>077.057.753</p>	 <p>Ref : X57911.0.51 Needle plate Brother XL3010-3022-3100-3200-4020-4021-4022-4023-4024-4025, VX1100, 1200</p> <p>077.057.911</p>
 <p>Ref : X58053.0.01 Needle plate Brother PC7000 BBL ESI, ESI-2</p> <p>077.058.053</p>	 <p>Ref : X58054.0.01 Needle plate Brother PC7000, PC7500, PC8000, M895 (no spring)</p> <p>077.058.054</p>	 <p>Ref : X58773.2.01 Needle plate Brother PE100 BBL EM1 (o.s. spring) If out, use XAO432001</p> <p>077.058.773</p>

NAALDPLATEN - PLAQUES AIGUILLES - NEEDLE PLATES BROTHER
SCHUIFPLATEN - COUVERCLES GLISSIERES - COVERPLATES BROTHER

 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: X58774.1.51 Needle plate Brother PE100 BBL EM1 o.s. (no spring)</p> <p>077.058.774</p>	 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: X59896.0.51 Needle plate Brother PS1250, 1800, 2150 BBL BL6200, BL6700</p> <p>077.059.896</p>	<p>Ref: X75822-001 = X75210-001 Needle plate Brother M760 Viking 560, 800, 900</p> <p>077.075.822</p>
 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: X75694-001 = X05060-001 Needle plate Brother 546D, 626D, 634D, 834DP, M526D Husky 535</p> <p>077.075.694</p>	 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: X76520-001 Needle plate Brother PL1600, PL2000, PL1500, M9600TD, M9800TD Viking 650ED, 660CD, 1001, 1001L</p> <p>077.076.520</p>	<p>Ref: X76528-001 Needle plate Brother PL1500 Viking 1000, 1000L</p> <p>077.076.528</p>
 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: X77087-001 Needle plate Brother 920, 934, M640, PC950, PC1500</p> <p>077.077.087</p>	 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: X77614-001 Needle plate Brother 925D, 935D</p> <p>077.077.614</p>	<p>Ref: XA0332.0.51 = XA0332.1.51 Needle plate Brother PS1000, PS1250</p> <p>077.332.151</p>
 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: XA0432.0.01 = XA0432.1.51 Needle plate Brother PE100 BBL EM1 new</p> <p>077.432.151</p>	 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: XA0647.1.51 Needle plate Brother VX1120, 1125, 1140</p> <p>077.000.647</p>	<p>Ref: XA2115.0.01 = XA2916.0.51 = XA2115.1.51 Needle plate Brother 8200 BBL ESE, ESANTE, ESP, ESE2, M945-955- 975</p> <p>077.002.115</p>
 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: XA3443.1.51 Darning plate Brother VX series NZ36LG</p> <p>077.003.443</p>	 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: XA3633.0.01 = XA3633.1.51 Needle plate Brother PE200, 150 BBL EM2 (with spring)</p> <p>077.003.633</p>	<p>Ref: XA3954.0.51 Needle plate Brother XL5010/1, 5020/1-5030/1- 5100 -5200-5300, PX100- 200-300, VX1400- 1140-1145-1250, BS2400/2155/2250, LS2720/2820/2920</p> <p>077.003.954</p>
 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: XA4937.0.51 Needle plate Brother PS2500, B373-375-376- 377</p> <p>077.493.705</p>	 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: XA6466.0.51 Needle plate Brother PQ1300, PQ1500</p> <p>077.006.466</p>	<p>Ref: XA8061.0.51 C/plate Brother 6452, 6552, XL6040/50/60</p> <p>077.008.061</p>
 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: XA8715.0.51 Needle plate Brother XL6562, 6452, 6040, 6050, 6060</p> <p>077.008.715</p>	 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: XA9438.0.01 Needle plate Brother ULT2001 BBL ESG</p> <p>077.009.438</p>	<p>Ref: XB0306.0.01 Needle plate Brother 929D, 1034D</p> <p>077.000.306</p>
 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: XC0413.0.51 Needle plate Brother PE300S, PE400D</p> <p>077.000.413</p>	 <p>N.V. LEON CALLOT S.A.</p>	<p>Ref: XC2364.0.52 Needle plate (B) Brother NV4000D</p> <p>077.002.364</p>	<p>Ref: XC2369.0.51 C/plate Brother NX200/400/600</p> <p>077.002.369</p>